



Muse X Gantry Alignment


In the right rear corner of the work area is the Y motor, drive shaft and coupler shown below.



We'll want to loosen the two black allen screws on the above coupler. Next push the X gantry towards the rear of the machine. Keep pressure on the X gantry and retighten the coupler.



Once the coupler is tightened we'll want to bring the X gantry to the front of the machine and ensure the X gantry is square with the front left and right corners.



For the last step we'll want to move the X gantry after checking the front corners back to the rear to ensure it is square there as well.